

92-2001 • WATERCOLOR FIELD EASEL ASSEMBLY/SET-UP INSTRUCTIONS



STEP 1. Begin by removing easel from carton.
See Fig 1 below.




FIG. 1

STEP 2. Unbuckle & Loosen leather strap, to release legs of easel. See Fig 2 below.




FIG. 2

STEP 3. After unbuckling strap, spread-out legs of easel and stand on their feet. See Fig 3 below.



FIG. 3

STEP 4. Loosen wing-nut on each leg to allow for height adjustment of legs. Tighten at desired height. See Fig 4 below.




FIG. 4

STEP 5. Once all legs are extended and secure, lower portion of easel should look similar to FIG. 5



FIG. 5



Martin/F. Weber Co.
4444 Lawton Avenue, Detroit, MI 48208 USA
Tel:(313)895-0700 • Fax:(313)895-0709
E-mail: Custservmud@aol.com
www.MartinUniversalDesign.com • www.weberart.com

92-2001 • WATERCOLOR FIELD EASEL

ASSEMBLY/SET-UP INSTRUCTIONS CONTINUED

STEP 6. To adjust lower canvas support holders, loosen wing-nut and slide to desired position and retighten wing-nut to secure. See Fig 6 below.




FIG. 6

STEP 7. Lever on side of easel is used to allow for adjustment of center column. Once desired angle/tilt or horizontal position is obtained, re-tighten lever to secure. See Fig 7.



FIG. 7


STEP 8. Fig. 8 shows how the center column support can be turned to allow for desired tilt of column, by loosening the lever on the easel.



FIG. 8

STEP 9. The adjustable canvas support located on the center column can be used for small canvases and large canvases.

To use the easel for larger canvases up to 33.5" H use position [A]. Position [A] allows the canvas support to be moved to the top of the center column. Secure canvas to lower canvas supports found on the two front legs. Secure by tightening wing-nut on canvas support.



[A] position can hold up to a 33.5" H canvas

To use the easel for smaller canvases 12.25" H canvas or less, use position [B]. This time flip center column around to other side of easel by loosening lever and re-tightening after center column is turned to rear of easel. See Fig. B



[B]

[B] position can hold a 1"H canvas to max 12.25" H canvas

FIG. 9

STEP 10.
Enjoy Painting!



Martin/F. Weber Co.
4444 Lawton Avenue, Detroit, MI 48208 USA
Tel: (313) 895-0700 • Fax: (313) 895-0709
E-mail: Custservmud@aol.com
www.MartinUniversalDesign.com • www.weberart.com