



Model 91-6008

IMPORTANT NOTICE
YOU WILL FEEL A SLIGHT
“BOUNCE-BACK” WHEN YOU SIT DOWN.
THIS IS NORMAL: NOT A DEFECT.
THE PNEUMATIC CYLINDER FOR THE SEAT
HEIGHT ADJUSTMENT REACTS TO YOUR
WEIGHT BY GIVING A LITTLE

Parts



A. [1] Base Plate & Lever



B. [1] Cylinder



C. [1] Backrest Support Bar
Note: Part [J] is attached to part [C]



D. [1] 5-Star Base



E. [5] Push-in Castors




F. [1] Backrest



G. [1] Seat



H. [1] Backrest Cover



I. [1] Footrest



J. [1] Knob
Note: This knob is attached to Part [C]




K. [4] Nuts



L. [4] 1 1/4" Bolts



M. [4] 5/8" Black Screws



N. [2] 1" Black Bolts



O. [1] Metal Backrest Plate

MARTIN
Universal Design, Inc.

4444 Lawton Street, Detroit MI 48208 USA

Tel:(313)895-0700 • Fax:(313)895-0709

Email: Custservmud@gmail.com


Visit us at:

www.MartinUniversalDesign.com

IMPORTANT


If you have difficulty assembling your chair or need customer service assistance. Please call: Martin Universal Design, Inc. Customer Service Hot Line at 1-800-366-7337. If you need additional parts, it is not necessary to contact your dealer, our Customer Service Rep. will forward them to you immediately.

1.




Place base (D) face down and push castors (E) in firmly. Insert cylinder (B) through base cap into chair base. Twist and press firmly.

2.




Attach foot bar (I) to base plate (A) using [4] 1 1/4" Bolts (L) and [4] nuts (K). Line up holes in footbar to holes in seat plate. Tighten securely.

3.




Attach Backrest Support Bar (C) to seat plate (A) by sliding the bar into the raised area of the seat plate (see arrow for location). Thread Knob (J) into hole in seat plate, making sure knob threads through seat plate.

4.




With seat cushion lying plastic side up, line up [4] holes in seat plate (A) with [4] holes in seat cushion (G). Attach with [4] 5/8" black bolts (M). Tighten securely. Please Note: Foot bar should face front of seat cushion (Front of cushion has label attached.)

5.




Take the complete seat assembly and insert the seat plate over the cylinder (B) by inserting the cylinder into the hole on the bottom of the seat plate (A).

6.




Attach backrest plate (O) to backrest support bar (C) by inserting backrest support bar "T" into longated slot in backrest plate (O). Continue with Step 7.

7.




If properly assembled, the backrest plate (O) and backrest support bar (C) should look like the above photograph. Once this is achieved move on to Step 8.

8.




Continue by taking the Backrest Cover (H) and placing it into position onto the backside of the backrest plate (O). NOTE: The metal backrest plate should lay flat against the backrest cover (H).

9.




The Backrest Support bar should now look like the above photograph. This Backrest Support Bar is now ready to have the backrest (F) attached to it. NOTE: Backrest Support should be attached to seat as displayed in Step 4.

10.



Attach Backrest Support assembly (Parts C, H & O) to upholstered back using the [2] 1" Black Bolts (N) provided making sure the screw holes in backrest cover (H) line up with the screw holes in the upholstered back. Tighten screws securely.

9.



IMPORTANT

If you have difficulty assembling your chair or need customer service assistance. Please call: Martin Universal Design, Inc. Customer Service Hot Line at 1-800-366-7337. If you need additional parts, it is not necessary to contact your dealer, our Customer Service Rep. will forward them to you immediately.

MARTIN
Universal Design, Inc.

4444 Lawton Street, Detroit MI 48208 USA
Fax: (313) 895-0709
Email: Custservmud@gmail.com
Visit us at:
www.MartinUniversalDesign.com