

IMPORTANT NOTICE

YOU WILL FEEL A SLIGHT
 "BOUNCE-BACK" WHEN YOU SIT DOWN.
 THIS IS NORMAL: NOT A DEFECT.
 THE PNEUMATIC CYLINDER FOR THE
 SEAT HEIGHT ADJUSTMENT REACTS TO
 YOUR WEIGHT BY GIVING A LITTLE

Parts



A. [1] Base Plate Mechanism



B. [1] Cylinder
 [a] 91-7706 model
 [b] 91-7709 model



C. [5] Castors



D. [1] Plastic Ring insert
 Model 91-7706 only
 (This part can be found in
 the foot ring Part F)



F. [1] Foot Ring with Knob
 Model 91-7706 only.



E. [1] 5-Star Base



I. [4] M6X20MM Hex Head Bolts



J. [6] M6X25MM Hex Head Bolts



Assembled 91-7706



Assembled 91-7709



G. [1] Backrest



H. [1] Seat



K. [1] Black Cylinder
 Bellows
 Model 91-7709 only



L. [2] Armrests

MARTIN

Universal Design, Inc.

4444 Lawton Street, Detroit MI 48208 USA

Tel: (313) 895-0700 • Fax: (313) 895-0709

Email: Custservmud@gmail.com


Visit us at: www.MartinUniversalDesign.com

IMPORTANT

If you have difficulty assembling your chair or need customer service assistance. Please call: Martin Universal Design, Inc. Customer Service Hot Line at 1-313-895-0700. If you need additional parts, it is not necessary to contact your dealer, our Customer Service Rep. will forward them to you immediately.




1. Place 5-star base (E) face down and push [5] castors (C) into each position.




2. Cut ends of plastic insert must run parallel with the weld.

THIS STEP IS ONLY FOR MODEL 91-7706 ONLY.
 Before attaching foot ring (F) to cylinder (B). Begin by loosening the knob on the foot ring and make sure the plastic rings inserted properly, by making sure the cut ends of the insert run parallel with the weld on the inside of the foot ring. The insert should be already in the foot ring. **NOTE: THIS MUST BE POSITIONED PROPERLY TO ALLOW THE CYLINDER TO SLIDE THROUGH THE INSERT EASILY.**



3. Slide cylinder down through foot ring and tighten knob. After chair is assembled completely, you may adjust foot ring to desired height.




4. **Model # 91-7706**
Model # 91-7709
PLEASE NOTE: If you have model number 91-7709, your assembly will be the same but instead of foot ring you will need to place black bellows over top of cylinder after inserting cylinder into base. Insert wider end of cylinder into hole in base, as shown above.




5. Attach mechanism (A) to seat (H) using [4] M6X20MM hex head Bolts (I). See picture above for specified locations that are circled. Tighten with hex wrench.



6. Attach backrest (G) to seat mechanism, by inserting backrest support bar into oval hole in mechanism. Tighten knob on mechanism to secure.



7. Attach armrests to bottom side of seat. Each Armrest (M) uses [3] M6x25 Bolts (J). Tighten with Hex-wrench.



8. Attach seat/backrest/armrest assembly to cylinder by inserting top of cylinder into hole on bottom of seat mechanism. Weight of sitting on seat will secure seat assembly to cylinder.

NOTE: 2 Paddles below seat are for seat height adjustment and Backrest tilt adjustments.

NOTE2: PERIODIC RE-TIGHTENING of Armrests screws may be needed throughout use of chair over the years.